



IVY

Bluetooth wireless rechargeable mouse




USER MANUAL


Before using this product, please read this manual carefully and save it for future reference

PRODUCT FUNCTION

Return rate: 125-250-500hz	Battery specification: 3.7V/500mAh
Sensor: Optical	Charging time: about 2-3 hours
Mode: Wired、2.4G、 Bluetooth	Interface: Type-c
Transmission distance: 8-10 meters	Weight: 66±5g
Number of keys: 6 keys	Size: 118*60*40MM
Switch life: left and right buttons 8 million times	Operating system: Compatible with USB interface/Bluetooth connection
	Personal computers, laptops and other devices




WIRED CONNECTION




Mouse plug in the data cable, data cable connected to the computer can be used

2.4G CONNECTION MODE



BLUETOOTH CONNECTION MODE

1. Move the switch at the bottom of the mouse to BT
2. Hold down [left button + Scroll button + right button] at the same time until the light at the scroll wheel of the mouse blinks continuously, indicating that the mouse is in the alignment state
3. Turn on the Bluetooth device, search and select the Bluetooth name "IVY" and then click the link, and start the Bluetooth pairing, after the success of the light off, the connection successfully used.



MOUSE CHARGING

Plug the Type-C data cable into the USB port of the computer, and then connect the mouse charging port position, you can charge the mouse, about 2-3,It can be filled in an hour.



Note: Do not use the fast charger to charge directly!!!

SYSTEM REQUIREMENT

Compatible with USB/Bluetooth connected PCS, laptops and other devices; Windows7 or later operating system.

SAFETY PRECAUTIONS

1. Keep the equipment dry, away from precipitation, moisture, all kinds of liquids and condensate.
2. Do not use this product with wet hands.
3. Do not use the fast charger to charge directly.

MOUSE SLEEP WAKE UP MODE

1. Stop the mouse for 60 seconds to go to sleep, and press the button to wake up.
2. Stop the mouse for 6 minutes to enter the sleep mode. When the computer enters hibernation mode, the mouse also enters deep hibernation. You need to press any key of the mouse to wake up the mouse, and then press any key to wake up the computer.



www.offbeatstores.com